



GrilleGuy.com, LLC

01-04 Honda Odyssey

Table of Contents

Upper Grille	Page 1-3
Lower Grille	Page 4-5
Fog Light Grilles	Page 6-7

Upper Grille Instructions



Step 1: Unpack your grille and get out some tools. You will need a small flat blade screwdriver and some diagonal cutters (scissors or nail clippers will suffice too).



Step 2: Open the hood and remove the quick push in fasteners. See the picture to the left. These are removed using the small screwdriver. Be careful or they can be damaged. Good news is you can get them at Lowes Home Improvement Warehouse.





GrilleGuy.com, LLC



Step 4: Remove the shroud, exposing the back of the OEM grille. The grille is now held in by three more of these similar fasteners. They are located on the back at the bottom, where the grille meets the bumper cover.



Step 5: Bend the brackets to an "L" shape.



Step 6: Use 2 of the screws from the OEM grille and the bracket to attach the grille using ty wraps.



GrilleGuy.com, LLC



Step 7: This is what it will look like with the grille removed. Here you can see the 3 points where the push-in fasteners are located. When reinstalling the grille you will use ty-wraps instead of the fasteners as they will not fit due to the interference with the grille. Below is a pic of our other Odessey grilles.





GrilleGuy.com, LLC

Lower Grille Instructions



Identify the top and front. Test fit the grille on the Odyssey. It does need a slight bend right in the middle. So test it and set that bend.

Take out the 4 attachment wires and bend them in the middle as shown.

NOTE: These instructions use the galvanized picture wire. WE SUPPLY zip ties. The wire can be found at your local Home Improvement warehouse.



Place the 4 attachment wires as shown around the middle horizontal plastic bar on the lower grille. Exact left and right placement is not necessary.



Using the soap you wash your car with clean this area and then leave it soapy and wet for easier sliding of the rubber on the fascia.



Start at left or right side and push the two ends of the attachment wire through two vertically adjacent holes in the grille that are right in the center. Twist the ends loosely now.



Move towards the center and insert the next attachment wire as you did the first and keep going until all four are done. They should all be very loose now. The grille is just hanging.



GrilleGuy.com, LLC



Position the grille to its final position. Now start on one end and tighten the attachment wires and then work your way to all four. Do not overwork the wire or it will break. If so you can get more at Lowes Home Improvement Stores. It is galvanized wire.



Tighten with needle nose and then cut off the excess. Not too short so it won't come back off but short enough to tuck the sharp ends into the opening where the snips are pointing. Push it easy so you don't break your wire. Wash as you would your car.





GrilleGuy.com, LLC

Fog Light Grilles

Tools: Drill and 3/8" bit



Identify the top and front of the grille. Test fit the grilles on the Odyssey.

Drill two 3/8 holes on the passenger side as shown. One hole above and one hole below the horizontal plastic fin. Drill slowly and it is clean enough.



Look underneath the car just below the fog lights and locate this area where my finger is. You can push this inside the fascia and reach your hand inside it.



Feed the zip tie from the back (inside fender well) and through the top hole you just made. Then through the grille (select the best hole on the grille). Then go back through the grill in the adjacent vertical hole (the one just below) and feed it back in to the fender well through your bottom hole. This is tricky as the hole is hard to hit but it can be done. Then you just complete the zip tie and pull it snug. I work with a lot of zip ties so I can do it with one hand but you may need two hands to get the zip tie into the block.

The driver's side is much easier and requires no drilling, but the process is the same.



GrilleGuy.com, LLC

