



GrilleGuy.com, LLC

## Install Instructions

### 03,04,05 Mazda 6 Lower Grilles

(does not fit SPORT model front bumpers)

#### Kit Contents:

3 Piece Grille (2 sides and 1 center)

12 40#, UV resistant zip ties

3 pieces of rubber trim

(flat blade screw driver and a hammer for trim installation – see Trim installation instructions).



This is what your Mazda 6 looks like before the GrilleGuy grille. That is about to change. Please allow approximately 30 minutes for the complete grille installation.

You will need to remove the upper grille to simplify the install by allowing you to access the back of the lower grille. You could opt to remove the under-pinning and come from the bottom of the vehicle, if needed. The upper grille is removed by removing

the fasteners from the top and then releasing the gibs where the grille meets the front bumper cover.



The lower center grille is removed by releasing the gibs and applying inward pressure on the honeycomb. It can then be rotated and pulled out thru the front. **ONLY REMOVE THE CENTER grille** if you are installing the fog grilles. The center grille alone can be installed with the OEM grille in place. For this reason we will cover the fog or side vent grille installation first.



The side vent grilles are removed in the same fashion as the center grille. To access the gibs either reach thru the front opening, the top, or from beneath. Once free from the gibs simply rotate the grille so that it will fit thru the opening.



GrilleGuy.com, LLC



To attach the grille to the side vent, 6 holes need to be drilled. Use 1/4" bit to drill the 6 holes in 3 sets of 2 placed in the corners of the side vent. These will never be able to be seen even if you choose to remove your aftermarket grille.

Attach the grille to the side vent LOOSELY. Be sure to place the locking mechanism on the back to eliminate visibility.



Replace the side vent in the vehicle and then locate the grille to the front bumper cover while tensioning the zip ties. No need to cut the excess off of the zip ties as no one will be able to see them. Repeat the side vent process for the opposing side



Replace the OEM center grille and then attach the grille using the provided zip ties. You can attach the grille with the method shown (the locking mechanism is directly against the back of the grille, this allows you to pull the zip tie from the front) or just latch the zip ties from the back if you have the upper grille still removed this is simple. We suggest placing the zip ties at the corners and then at the top and bottom at the center.



Replace the center upper grille and you are done!