



GrilleGuy.com, LLC

then 2 holes in your latch. Use 2 screws or tie wraps to attach the rod to the latch. You will now be able to release the hood from below the grille. There are many ways to make this work, so if you put your mind to it you can come up with a alternate idea.

Step 2 – Determine if you want to remove the slats or horizontal braces from your OEM grille. If you want them removed for the best appearance, you'll have to cut them away with a small hacksaw blade. The nfinish up with a file to smooth the edges. NOTE: You cannot UNDO this step, so be sure to take your time.

Step 3 – Attach the grille to the backside of the OEM grille. You can attach to the frame of the OEM grille using the supplied zip ties. Do not over tighten; it is possible to damage the grille during tightening.

You are done!