



GrilleGuy.com, LLC

Attaching the plastic trim.

- The plastic trim serves to protect your car from the sharp edges of the grille. Use a screwdriver, or other flat object, to run down the middle of the trim. This will open the trim slightly and make for a much easier application.
 - Push the trim onto the edge of the grille while stretching the trim slightly as you go around. The trim is easily cut with diagonal cutters or snips. Your grille may look a little awkward at this point due to variability in the cut of the grille material, not to worry. **After your grille is installed, push the trim out from the grille until it is flush with the surface on your automobile,** this should give the grille the exact shape of the opening on your car.
 - For best results start the trim in the top center of the grille to give it a more symmetric look.
-

*Special Note for 2000 - 2005 Chevy Tahoe & Suburban
1999-2002 Chevy Silverado

The trim attaches as shown in the photo below, there is NO trim around the notch in the lower grille.

